# narbutas.com

# SILENT ROOM

Ordering guidelines



SILENT ROOM 2

# Other documents available for this product

Technical information for SILENT ROOM S, M, L, XL User manual for SILENT ROOM Troubleshooting manual for SILENT ROOM Technical guide for SILENT ROOM

This guide was designed to make the ordering process of the SILENT ROOM acoustic pods system easier. Here you will find the most common combinations and explanations regarding which parts you should order for the desired combinations.

For your convenience you can also use product templates in online pricelist and adjust them according to your needs.

The following guidelines are applicable for SILENT ROOM acoustic pods of all sizes due to the same ordering principles. However, there are some exceptions based on selected size. The pictures in this document represent SILENT ROOM L parts unless specified otherwise.

SILENT ROOM | step 01 3

# Basics of ordering SILENT ROOM acoustic pods

# 01

# Choosing external walls

External walls are available in four versions:



External walls should be selected based on your requirements and needs.

Colours of external walls upholstered with fabric should be ordered following the rule from the top of the combination: 1 + 2 + 2.




If you order external walls with glass panes, skip Step 03.

#### 02

# Ordering internal acoustic walls

Colours of the internal acoustic walls should be ordered following the rule from the top of the combination: 1 + 2 + 2.




### 03


# Choosing internal front walls

If you order external walls with glass panes, skip Step 03.

Internal front walls are available in two versions:


Colours of the internal front walls upholstered with fabric should be ordered following the rule from the top of the combination: 1 + 2 + 2.





Melamine





SILENT ROOM | step 04 5

#### 04

# Choosing media wall for SILENT ROOM S

SILENT ROOM S media wall is available with AC power socket and either integrated USB fast charger type-A and type-C or without it.





## Choosing media wall for SILENT ROOM M, L, XL

SILENT ROOM M, L, XL media wall is available with low or high table and without it.







Media walls are suitable for power socket or power unit installation. Electrical components should be ordered separately.

If you are planning to install a TV, we recommend to order a power unit ZZZ336. Please check if standard of VESA bracket (75x75 mm and 100x100 mm) is compatible with your flat screen.











SILENT ROOM | step 05

# 05


# Choosing glass door


Glass doors are available in L/H or R/H option for SILENT ROOM S acoustic pods.





Glass doors can be L/H or R/H and are available with a lockable lock set option for SILENT ROOM M, L and XL acoustic pods.





Place of the SILENT ROOM XL doors should be selected during the assembly. We do not recommend placing the door on the same side as the media wall.






SILENT ROOM | step 06/07

#### 06


# Ordering the ceiling

The ceiling includes LED lights and ventilation. Please order according to the selected SILENT ROOM size.

SILENT ROOM S SILENT ROOM M SILENT ROOM L SILENT ROOM XL









# 07

# Ordering the floor

This step is optional for the SILENT ROOM S, M and L acoustic pods. The floor is mandatory for the SILENT ROOM XL.

# Ordering the carpet

It is highly recommended to use the carpet when placing the SILENT ROOM S, M or L on the hard flooring (1). If you are planning to place the SILENT ROOM on your carpet, you do not need to order the additional carpet (2).



