


## RON


31-Mar.-2017






SAFETY DISTANCE FOR HALOGEN LAMPS








## MOUNTING INSTRUCTION

Make a hole in the ceiling according to the prescribed dimensions.


## **POWER CONNECTION**

SERIAL CONNECTION - for LED

Always use POWER SUPPLY according to the specifications of the LED-module



PARALLEL CONNECTION - for PAR16



- 3 Insert the lamp into the inner part of the RON and fix with spring
- (4) Click the inner part of the RON into the outer part

## ADVICE FOR EASY INSTALLATION

- Press the springs of the middle fixture together and bind them with the delivered strap.
- Move the fixture partly into the ceiling and cut the strap
- Guide the device in place perfectly



