

MEASUREMENT FOUNDATION

Operating manual

Laser receiver Model: LR - 60



Manufacturer: ADAINSTRUMENTS

Address: WWW.ADAINSTRUMENTS.COM



LR - 60

Features



- 1. On/Off button
- 2. Signal LEDs
- 3. Bubble level
- 4. Sensitive element
- 5. Sound Off button
- 6. Dynamic loudspeaker
- 7. Clamp on the staff
- 8. Battery cover



Specifications

Accuracy	
Service time	
Power supply	
Size	

±1mm/10m 30h 1x9V, type 6LR61 150x50x25 mm

Battery installation

Open battery cover. Place 1x9V (type 6LR61) battery. Close battery cover.

Fixation on the staff

Fix the receiver LR-60 on the staff as it shown on the picture.

Application of the detector

Application of the detector is a decisive advantage when working outside in sunny weather. Press button On/Off to switch on the detector mode. Bring the receiver to the place of beam location. When laser beam will be on the sensitive element, there will be sound alarm and one of the LEDs (A or C) will flash. LED will show the direction for the receiver for beam detection. Move the receiver until you will hear continious sound alarm and middle signal LED (B) will flash. With the help of bubble level check the leveling of the receiver housing. Mark the surface or remember the height results if the receiver was set on the staff.





LR - 60





Warranty

This product is warranted by the manufacturer to the original purchaser to be free from defects in material and workmanship under normal use for a period of two (2) years from the date of purchase.

During the warranty period, and upon proof of purchase, the product will be repaired or replaced (with the same or similar model at manufactures option), without charge for either parts of labour.

In case of a defect please contact the dealer where you originally purchased this product. The warranty will not apply to this product if it has been misused, abused or altered. Withiut limiting the foregoing, leakage of the battery, bending or dropping the unit are presumed to be defects resulting from misuse or abuse.

Exceptions from responsibility

The user of this product is expected to follow the instructions given in operators' manual.

Although all instruments left our warehouse in perfect condition and adjustment the user is expected to carry out periodic checks of the product's accuracy and general performance.

The manufacturer, or its representatives, assumes no responsibility of results of a faulty or intentional usage or misuse including any direct, indirect, consequential damage, and loss of profits.

The manufacturer, or its representatives, assumes no responsibility for consequential damage, and loss of profits by any disaster (earthquake, storm, flood ...), fire, accident, or an act of a third party and/or a usage in other than usual conditions.

The manufacturer, or its representatives, assumes no responsibility for any damage, and loss of profits due to a change of data, loss of data and interruption of business etc., caused by using the product or an unusable product.

The manufacturer, or its representatives, assumes no responsibility for any damage, and loss of profits caused by usage other thsn explained in the users' manual.

The manufacturer, or its representatives, assumes no responsibility for damage caused by wrong movement or action due to connecting with other products.

WARRANTY DOESN'T EXTEND TO FOLLOWING CASES:

1. If the standard or serial product number will be changed, erased, removed or wil be unreadable.

2. Periodic maintenance, repair or changing parts as a result of their normal runout.

3. All adaptations and modifications with the purpose of improvement and expansion of normal sphere of product application, mentioned in the service instruction, without tentative written agreement of the expert provider.

4. Service by anyone other than an authorized service center.

5. Damage to products or parts caused by misuse, including, without limitation, misapplication or nrgligence of the terms of service instruction.

6. Power supply units, chargers, accessories, wearing parts.

7. Products, damaged from mishandling, faulty adjustment, maintenance with low-quality and non-standard materials, presence of any liquids and foreign objects inside the product.

8. Acts of God and/or actions of third persons.

9. In case of unwarranted repair till the end of warranty period because of damages during the operation of the product, it's transportation and storing, warranty doesn't resume.

WARRANTY CARD

Name and model of the product			
Serial number	_date of sale		
Name of commercial organization	stamp of commercial organization		
Warranty period for the instrument explotation is 24 months after the date of original retail purchase.			
During this warranty period the owner of the product has the right for free repair of his instrument in case of manufacturing defects.			
Warranty is valid only with original warranty card, fully and clear filled (stamp or mark of thr seller is obligatory).			
Technical examination of instruments for fault identification which is under the warranty, is made only in the authorized service center.			
In no event shall manufacturer be I occur in the result of the instrumen	iable before the client for direct or consewuential damages, lo toutage.	oss of profit or any other damage which	
The product is received in the state of operability, without any visible damages, in full completeness. It is tested in my presence. I have no complaints to the product quality. I am familiar with the conditions of garranty service and i agree.			

purchaser signature _____

Before operating you should read service instruction!

If you have any questions about the warranty service and technical support contact seller of this product