

Mounting instruction

ECOFLEX®10

7-16DIN Socket, screw/solder / Art. No. 7388



- 1.** Cut off cable tail right-angled. Move the nut, clamping ring and rubber washer over the cable head.
Hint: With a bit of Vaseline the rubber seal can be slided easier over the outer sheath.



- 4.** Remove the copper foil and the foamed dielectric just at the contact sleeve.



- 2.** Remove 5 mm of the outer sheathing with a knife..



- 5.** Put the inner pin with the thread onto the inner conductor and solder it.



- 3.** Bend copper braid upwards right-angled. Slide the contact sleeve as far it goes between the copper braid and the foil and remove the exceed copper braid with a side cutter..



- 6.** Insert the so prepared cable end into the connector housing. Hand tighten the clamping nut with a 17mm and a 24mm open-end wrench and screw the contact onto the thread of the inner pin.