
Exploded Drawing MAN ALL



·10·







	co)	
	Photo	HUBEN 🐉
as'	.0	m
Item	Photo	Specification
1	= 20	Receiver House
2	0	Metal Seal of Opening Valve
3	0	Plastic Seal of Opening Valve
4	0	Opening Valve O-Ring 11.6x1.8 NBR90
5		Opening Valve
6	• 50	Striker Plastic Cap Cover
7		Striker
8,5	WWW	Striker Spring 7x31x1
9	0	Striker Buffer
10		Receiver Back Cover Plate
11	*	Receiver Back Cover Plate Allen Screw M5x14
12	•	Rear Sight Base Height Adjust Screw M3x6

Item	Photo	Specification
13		Rear Sight Base Pin 1x15
14		Rear Sight Base Adjust Screw
15		Rear Sight Base
16	****	Rear Sight Adjust Spring 4.5x8x0.6
17	-	Rear Sight
18	wa	Rear Sight Base Spring 4x4x0.5
19	MAN	Close Valve Spring
20		Plastic Close Valve
21	 	Close Valve Spring Stem
22		Close Valve Dynamic Wheel Adjust Spring
23	•	Close Valve Brass Housing Internal to Stem Seal
24	0	Close Valve Brass Housing Internal Seal Btm 6.4x1.2 NBR90

·12·





	Sel	
	Photo	HUBEN WAS ALTERED TO THE STATE OF THE STATE
as'		2002/34 x 15,000 (d)
Item	Photo	Specification
25	0	Close Valve Brass Housing Internal Seal Top
26	0	Close Valve Brass Housing O-Ring 17x1.5 NBR90
27	Ŧ	Brass Close Valve Housing
28	ARTINE .	Dynamic Power Adjust Screw M6x8
29	F	Striker Sear
30	1,50	Striker Sear Catch Pin Φ3.5x16
31		Sear Spring 5.3x13x0.5
32	7	Sear Catch
33		Trigger Arm Pin Φ3x17
34	6	Sear Catch Arm
35	I	Trigger Arm
36		Sear Catch Arm Pin Φ3x19

Item	Photo	Specification
37	•	Black Plastic Receiver Pin Cover 3 x 5.6
38	•	Black Plastic Receiver Pin Cover 3.5 x 5.6
39	ARRANGE .	Trigger Tension Fine Adjust Spring 2.5x11x0.5
40		Trigger Tension Fine Adjust Spring Base M5 x 10
41	0	Pressure Gauge O-Ring 4x1.5 NBR90
42	•	Pressure Gauge
43	1	Magazine Indexing Arm
44		Magazine Indexing Spring
45		Plastic Housing for Magazine Indexing Arm
46		Magazine Release Arm Tension Spring 2.9x30x0.6
47	•	Magazine Release Pusher
48		Magazine Release Arm Housing

·14·





	co'	
	Photo	HUBEN (
an'	.0	months of the control
Item	Photo	Specification
49	-	Magazine Release Arm
50		Magazine Release Arm Pin Φ2x8
51	7	Magazine Release Assembly Allen Screw M3x8
52	Ţ	Brass Safety Lever
53	٠	Safety Lever Detent Ball
54	250	Safety Lever Detent Ball Spring 3x5.5x0.6
55	il Chi	Safety Lever Adjust Tension Allen Set Screw M4x6
56		Screw on Top of Receiver M3.5X8
57	0	Air Mag Index Assist Pin O-Ring 4.5x1.2 NBR90
58		Air Mag Index Assist Pin Φ2.5X11
59	0	Brass Insert Screw O-Ring 4.5x1 NBR80
60	<u> </u>	Brass Insert Screw for Air Assist Magazine

Item	Photo	Specification
61	•	Magazine Plastic Side Cover
62	A	Magazine Plastic Side Cover Allen Screw M3x6
63	0	Breech Seal O-Ring 11.5x1.5 NBR90
64	0	Plastic Breech to Magazine Seal
65	0	Magazine (specify177 & .22 are 19 shots / .25 is 17 shots)
66	0	Magazine Front Cover
67	0	Bearing of Magazine
68		Magazine Stop Retaining Pin Φ2x10
69	6	Magazine Stop
70	6%	Magazine Stop Guide (specify177 & .22 & .25)
71		Magazine Stop Guide Spring Pin Φ1.5x15
72		Magazine Stop Guide Spring

·16·





	HUBEN Specification		
	airdinas	HUBEN	
Item	Photo	Specification	
73	6	Magazine Base	
74	1	Barrel Housing Base	
75	7	Magazine & Barrel Housing Bases to Receiver Fasten Screw M4 x 12	
76	-	Magazine Base and Barrel Housing Base Fasten Screw M3 x 14	
77	6	Barrel Retain Nut M12x1	
78	7,50	Barrel Housing to Receiver Allen Screw M3x35	
79		Barrel Shroud Retaining Pin Φ2x8	
80	· -	Barrel (specify177 & .22 & .25)	
81		Barrel Shroud	
82	Ħ	Barrel Shroud End Cap	
83		Pressure Tube End Cap	
84	0	Pressure Tube O-Ring 29.5x2 NBR90	

Item	Photo	Specification
85		Titanium Pressure Tube
86		Pressure Tube Connector
87	0	Pressure Tube Connector O-Ring 11.5x1.5 NBR90
88	0	Fill Stop O-Ring 6.4x1.2
89		Intake Valve
90	0	Intake Valve Cover O-Ring 9 x 1.2
91		Intake Valve Cover
92	⊕	Trigger Guard
93	(Trigger
94		Trigger Retaining Pin Φ2.5x12
95		Trigger Guard Locker
96	-	Trigger Guard Locker Screw M5x25

·18·