## MAP


25-Sep.-2017

### 0.6 LED 5W | 220-240VAC | 50-60Hz | COB 3-step | incl. power supply 3000K | >80CRI | 150lm 751163I4 inox OPTIONAL 90012201 recessed housing 0.9 $\blacksquare ED \ 8W \ | \ 220\text{-}240 \text{VAC} \ | \ 50\text{-}60 \text{Hz} \ | \ COB \ 3\text{-step} \ | \ incl. \ PS \ | \ phase-cut \ dim$ 3000K | >80CRI | 480lm inox 751264I4 OPTIONAL recessed housing 90012202 1.2 $\fbox{LED}\ 12W|\ 220\mbox{-}240VAC\ |\ 50\mbox{-}60Hz\ |\ COB\ 3\mbox{-}step\ |\ incl.\ PS\ |\ phase-cut\ dim$ (€ □ |P67 (]-0,3m-|E @ ▼ ■ □ □ 3000K | >80CRI | 750lm beam angle 38° inox 751364I4 OPTIONAL recessed housing 90012203 1.6 $\blacksquare$ 15W | 220-240VAC | 50-60Hz | COB 3-step | incl. PS | phase-cut dim (€ □ IP67 (]-0,3m-₺ ஞ ▼ • □ □ □ 3000K | >80CRI | 950lm beam angle 38° 751464I4 inox OPTIONAL 90012204 recessed housing


The MAP 0.6 has an auto-recovery thermal fuse. In order to avoid product early failure in some extreme condition; If the internal components reach a temperature of 85°C, the product will switch off and then restart when cooling down.

## with recessed housing






OPTIONAL, (ORDER SEPARATELY)




#### **DIMENSIONS**




### MOUNTING INSTRUCTION

Remove the protective foam inside of the MAP.

Make sure to screw the screws back on, crosswise, to ensure IP67



- Make a hole in the ground according to the prescribed dimensions (of the recessed housing)
- 3 Drainage: we recommend that all exterior groundspots should be installed with a drainage level even when using a recessed housing





#### **POWER CONNECTION**

Exterior: WATERPROOF Connection





Remark: Do not open or cut off the Water Stopper on cable.

MOUNTING WITH RECESSED HOUSING

Use the bolts and the nuts to attach the MAP to the recessed housing



The light source of the integrated LED is not replaceable; Caution, risk of When the light source reaches its end of life the whole luminaire shall be replaced.




# **MAP**


25-Sep.-2017


O.6  LED 5W   220-240VAC   50-60Hz   COB 3-step   incl. power supply  C€ □   P67	751163 <b>I</b> 4
OPTIONAL recessed housing	90012201
O.9  [LED] 8W   220-240VAC   50-60Hz   COB 3-step   incl. PS   phase-cut dim  (€ ☐    P67	751264I4
recessed housing	90012202
T.2	751364I4 90012203


# without recessed housing

**A.** Attached to the floor (or wall, for wall mounting)












**A.** Attached to the floor (or wall, for wall mounting)

Use the screws to attach the MAP to the floor or wall. Make sure to measure correctly so that you can screw onto a hard material.

This type of installation is not possible for MAP 0.6







The MAP 0.6 has an auto-recovery thermal fuse. In order to avoid product early failure in some extreme condition; If the internal components reach a temperature of 85°C, the product will switch off and then restart when cooling down.



The light source of the integrated LED is not replaceable; Caution, risk of When the light source reaches its end of life the whole luminaire shall be replaced.



beam angle 38°

inox OPTIONAL recessed housing 751464I4

90012204


## MAP


25-Sep.-2017


### 0.6 3000K | >80CRI | 150lm 75116314 inox OPTIONAL 90012201 recessed housing 0.9 LED 8W | 220-240VAC | 50-60Hz | COB 3-step | incl. PS | phase-cut dim 3000K | >80CRI | 480lm inox 751264I4 OPTIONAL 90012202 1.2 $\fbox{LED}\ 12W|\ 220\mbox{-}240VAC\ |\ 50\mbox{-}60Hz\ |\ COB\ 3\mbox{-}step\ |\ incl.\ PS\ |\ phase-cut\ dim$ 3000K | >80CRI | 750lm beam angle 38° 75136414 inox OPTIONAL recessed housing 90012203 $\fbox{LED}\ 15W|\ 220\text{-}240VAC\ |\ 50\text{-}60Hz\ |\ COB\ 3\text{-}step\ |\ incl.\ PS\ |\ phase-cut\ dim}$ (€ □ IP67 (]-0,3m-₺ ஞ ▼ • □ □ □ 3000K | >80CRI | 950lm


## without recessed housing


B. Rests on the stainless steel borders of the fixture












- B. Rests on the stainless steel borders of the fixture
- 5 Place the MAP into the hole, no tools needed to fix it into the hole. Just let it rest on the stainless steel borders of the fixture



The MAP 0.6 has an auto-recovery thermal fuse. In order to avoid product early failure in some extreme condition; If the internal components reach a temperature of 85°C, the product will switch off and then restart when cooling down.



The light source of the integrated LED is not replaceable; Caution, risk of When the light source reaches its end of life the whole luminaire shall be replaced.



beam angle 38°

inox OPTIONAL recessed housing 751464I4

90012204